



**CONSTRUCTION NOTES:**

- A. Install Tank after other site construction use of heavy equipment that must cross the bed area.
- B. Mark edges of the Tank bed during and after construction to prevent heavy equipment from crossing the Tank bed area.
- C. Stabilize area surrounding the Tank bed to prevent washing of silts/sediment into the bed.
- D. Remove silts/sediment from erosion that washes into the bed during construction.
- E. Subgrade base must be compacted to 95% modified proctor, leveled after final grading.
- F. Fill materials shall be per the engineer's specification, free of lumps, debris or other sharp materials and excess silt.
- G. Do not cut holes in the Tank except as shown in ET-1207 drawing.
- H. Read manufacturer's submittal and use the attached checklist to ensure proper installation.

## Eco-Rain Tank Cross Section A-A With Geogrid for Traffic-Rated Applications